



### Features

---

Compact size, Quick response, No touch health design, Flash Light and Three BAC indication levels:

**green < 0,02%BAC**  
**yellow > 0,02%BAC**  
**red > 0,05%BAC**

### Technical Information

---

Advanced NM semi-conductor alcohol sensor  
Warm-up time < 15 seconds  
8 second response  
Approx. 50 gm including batteries  
Detecting range: 0.00-2.00g/L  
(0.00-0.20%BAC)/0.00-1.00mg/L  
Accuracy: Calibrated to indicate alcohol level within 10% of 0.05% BAC  
Pre-set limit: Two level concentration (0,02%, 0.05%BAC)  
Power supply: 2 x AAA batteries  
Working environment: 0-50 <95% RH (No condensation)  
Dimension 64mm x 35mm x 21mm  
Battery saving design

The AT-Series Key Ring Breath Alcohol Tester can be used for quick detection of alcohol in the breath. Gives a yellow light warning indication for 0,02%BAC and gives a red light warning when exceeding the pre-set limit of 0,05%BAC.

### Easy to use

---

Press power on button.  
Wait for 5 to 10 seconds warm up.  
A "ready" green light will be displayed.  
Blow into the air hole for 3 seconds from a 2-3cm distance.  
The relevant indicator light will inform your %BAC.  
Switch off power supply.

This model can be branded for companies that would like to give away as part of public awareness campaigns or as corporate gifts. Please send an email or call for a quotation

---

**Alcohol Breathalysers CC, 25 St John Road, Houghton Estate, Johannesburg, 2198**  
**Tel: 011 023 8955 / 6 / 7 Fax: 011 648 0155**  
**Website: [www.breathalysers.co.za](http://www.breathalysers.co.za)**